

Paint Sticks : Instructions and general information

Instructions

- 1. Ensure the area requiring treatment is free from any dust, dirt or grease, do not use any aggressive cleaners as this may do more harm to the paintwork than good! In the case of any surface rust, carefully remove with very fine emery paper.**
- 2. Shake the paint-stick for approximately one to two minutes before use.**
- 3. Apply the paint thinly to the damaged area. CAREFUL : Apply the paint sparingly, ensuring there are no air bubbles or drips and always place the pen carefully on a table and even surface when open to avoid unwanted spills!**
- 4. Every coat necessary requires approximately one hour to dry.**
- 5. When metallic or matt paints have dried they require an extra coat of clear lacquer paint, according to type. Normal paints do not require this extra treatment.**
- 6. Leave the repaired area at least twenty four hours to dry properly.**
- 7. Polish the repaired area, after drying, using a specialised paint-work polish. If the paint applied is too thick it can be gently levelled using a fine graded emery paper (ca.2500).**